

Frame size: 70 x 100 cm

**Lightbox frame**This frame can be used single- or double sided. You always need fabric graphic on both side (printed or unprinted), unless you will use it as a wall mounted frame on a white wall, in which case it's not necessary to use fabric on the reverse side.

# Start / End profile 700 mm - Item IS-Special Start / End profile 1000 mm - Item IS-9598 Start / End profile 1000 mm - Item IS-9598 Start / End profile 700 mm - Item IS-Special

# **VERY IMPORTANT!**

Before you connect the LEDbar, read how to connect! See reverse side.

### Mount the frame

You must lock all joints with screw brackets in each side.



Corner connection.



Straight connection.

# Mount the feet

Item no: IS-9338 (Minimum 2 pcs.)
The frame must be drilled for the feet on the bottom profile.



Mount a foot in each side of the bottom profile.



# **Mount the LED-bar**








2 Lock the two screws with the Allen-key.




3 Insert the adaptor cable in the hole in the profile. Each hole fits 2 cables.



Connect the contacts from the LED-bar to the adaptor cable.



5 Add more LED-bars and connect with that before, approx 10 mm from the first one.



Hide the cable in the side slot and secure it with a tape

# **Connect the LED-bar and transformer**

